

Steering Installation Instructions

For Questions Call Gramlow Ltd @ 701.375.6330

Pictured to the right is the Steering Indicator Box. First locate a suitable place to mount this box in the tractor cab. Once mounted, route the 6.5 foot power supply harness from steering box to 12 volt keyed power source in the cab. Ensure cord is safe and secure in tractor cab. Next, route the 25 foot sensor harness out the back window and down to the hitch. Connect harness at the hitch with customer supplied extension cable. Finish routing the cable to the steering angle sensor on the planter axle.



*Be sure to fasten all wires in a secure position so they do not get caught or frayed.

Next Step: It is necessary to adjust the system to 2.5 volts. This reading is taken when the tracks are centered straight forward. When all three holes are lined up, as shown in the first picture below, this means that the tracks are perfectly centered and straight. Insert a paper clip as shown in the photo on the right. Using a volt meter adjust the sensor linkage to read 2.5 volts.

